

#124107

**Rear 1" Heavy Duty Extended Shackles
1984-2001 Jeep Cherokee XJ**



**READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR
TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.**

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the front wheels for safety.
2. Raise the rear of the vehicle and support with jack stands ahead of the rear spring hangers.
3. Support the rear axle with a hydraulic jack and remove the driver's and passenger's rear shackles. Retain all hardware and discard shackles.
4. Apply a thin layer of grease and install the provided bushings and sleeves in the new shackles.
5. Install the provided grease fittings in the thread hole in the shackle.
6. Locate the bumper bolt that is protruding into the shackle pocket. This bolt will contact the new larger shackle through suspension travel. The bolt can either be cut off flush with the welded nut on the body or removed.
7. Install the new shackles in the OE locations with the original hardware. Leave the spring and shackle bolts loose at this time. The grease fittings should be toward the front of the vehicle.
8. With both shackles installed, lower the vehicle to the ground.
9. Bounce the vehicle to settle the suspension and torque the shackle mounting bolts to 65 ft-lbs.
10. Grease the upper shackle pivots with lithium based grease.
11. Check all hardware after 500 miles.